



Instructions

Vacuum Cleaner Usage

General use

- Depending on the equipment provided by the client, **prefer a lightweight and compact vacuum cleaner** with a telescopic handle.
- Check that the appliance is **ready for use**:
 - Bag or dust container emptied.
 - Filters clean.
- **Preferably use**:
 - A cordless vacuum cleaner.
 - A handheld vacuum cleaner for hard-to-reach areas.



Noise levels

- The vacuum cleaner must not exceed **85 dB**.
- **Useful information**: Vacuum cleaners of 86 dB or more are very rare. A noise level above 85 dB is, for example, that of a gas-powered lawn mower.
- **Beware of hearing damage** in case of prolonged exposure to noise.

Time limit

- Vacuum for a **maximum of 1 hour** per 4-hour work period.
- **Regularly alternate** with other tasks to avoid physical overload.



Safety during use

- Work with a **straight back**, avoid bending over.
- **Avoid carrying heavy vacuum cleaners** on stairs.
- On stairs:
 - Did you know that cleaning stairs with a mop is not only more practical, but also safer and more effective? **Opt for a mop for optimal results!** If you nevertheless use a vacuum cleaner, **choose a cordless and lightweight model** for greater safety and comfort.
 - **Never use an industrial vacuum cleaner.**

Safety devices

- Presence of a **stair railing**.
- **In the absence of a railing:**
 - It is forbidden to carry equipment on the stairs.
 - Ask the client if they can prepare the necessary equipment upstairs in advance.

What to do in case of malfunction?

- **Stop immediately in case of:**
 - Abnormal noise
 - Smoke
 - Unusual odors
- **Report the problem to the client.**