




Safely ironing

Before starting

- ✓ Set the height of the ironing board correctly: we recommend setting the height of the board so that the ironing surface is about 25 cm lower than your elbow.
- ✓ Pick up the iron via the handle and place it on a stable surface.
- ✓ Place the laundry basket on a chair. This way you won't have to bend down every time and avoid hurting your back. Don't place the chair with the laundry basket immediately next to the ironing board, but a little further away to avoid twisting. A little more exercise is also healthy. 😊
- ✓ Limit distractions while ironing, such as making phone calls or talking to customers.



Be aware

- ✗ Never touch the hot underside of the iron. Keep your hands away from the iron while using it.
- ✗ Keep the iron away from the cord.
- ✗ Never steam in the direction of people or animals.
- ✗ Set the temperature according to the type of fabric.
- ✗ Always stay nearby when the iron is on or still hot. Do not get distracted.
- ✗ Do not move the steam container while it is still hot. Refill the water through the opening provided for this purpose.
- ✗ Lay the cord nicely aside. Both during and after ironing. So that no one trips over it. Not even you!
- ✗ Cleaning the iron? Let it cool down for at least 2 hours. Never immerse it in water or any other liquid.
- ✗ Does the iron indicate a fault? Is the appliance or the cord damaged? Unplug the appliance immediately. Do not pull the cord itself.
- ✗ If it is an iron with automatic power generation, switch this function off (if possible).

Ready?

- ✓ Unplug the power cord. Do not pull on the cord itself.



- ✓ Make sure the iron has cooled down before moving it.
- ✓ Empty the reservoir before storing it. Only a small amount of water should remain in the reservoir so that the circuit does not dry out.
- ✓ Provide a storage place that is not above the shoulders.

Ironing like a pro?

Consult safety fiche no. 9, ironing of linen, for housekeepers during your start-up.